







<p>15" Flat-Panel Video Monitor in Hardcase for Control Console</p>	<p>This accessory consists of a Pelican Hardcase to house the Basic Control Console (provided with the vehicle on Page 1) and a 15-inch Flat-Panel Color Video Monitor for razor-sharp viewing. Also incorporates antenna plugs to connect video and control antennas (see Page 2).</p>	
<p>Overview Color Camera, with Pan, Tilt, Zoom and LED Floodlight</p>	<p>The overview camera is mounted on a stalk and combines remote-control zoom, pan and tilt, augmented with a bank of LED floodlights. It gives a selectable view separate from the other cameras, which can be recorded at the control console on video disk or cassette.</p>	
<p>Zoom Option on Driving Camera or Wrist Camera</p>	<p>Although we do not recommend this option because it is disorienting to the operator, we can equip the driving camera and/or the hand camera with zoom capability.</p>	
<p>Color Option on any b/w Camera</p>	<p>If desired we can provide any camera in color.</p>	
<p>Halogen Floodlight</p>	<p>Not required for the video cameras - they have built-in LED floodlights and produce good images at very low light levels - but some operators prefer to have floodlight illumination available for human eyes..</p>	
<p>Carrier for X-Ray Source, plus Holder for 8 x 10" X-Ray Film Cassette or Digital Imager</p>	<p>For taking X-rays of objects remotely, MURV-100 places Film Holder behind object, aims X-ray source in Carrier, triggers it via remote firing circuit, then brings Film Holder back to operator. Recommended X-ray sources are Golden Engineering's XR-150 or XR-200.</p>	
<p>Quad Video Display Option (4 views)</p>	<p>This option lets the operator toggles a switch to show either four images or one image on the monitor. In the "4" position, the views from all four robot cameras appear on the monitor at the same time; In the "1" position only one camera's view is seen, with the viewing camera selected by the "Camera Select" switch in the normal manner.</p>	